

Hay Hygrometer PCE-HMM 200







Hay hygrometer to determine moisture and temperature of hay and straw / Robust design / Four different lengths of measuring lance of 25 cm, 50 cm, 100 cm or 200 cm /

Continuous display of measuring value

The hay hygrometer PCE-HMM is a professional device to designed to determine moisture and temperature of pressed hay and straw. The hay hygrometer features a sensor made of stainless steel, which can be purchased in four different lengths, while the wooden handle has an ergonomic design. The hay hygrometer PCE-HMM proves to be extremely robust, designed to withstand applications for many years. The measuring range of the hay hygrometer covers 9 ... 50% and a temperature range of -10 ... 100°C / 14 ... 212°F. The LCD display of the hay hygrometer shows continuously the current moisture, so the hay hygrometer can be applied at varying locations and on different bales without the need of performing any manual operation by pressing any keys to start the measurement. Thus the hay hygrometer facilitates assuring the quality of fodder even during harvesting in order to prevent any damage by fungal infestation.

- ► Controlling moisture of harvest during trading
- Safety precaution during storage of hay and straw
- ▶ Assures fodder quality and prevents damages due to fungal infestation.
- ► Temperature control
- ▶ Robust measuring device for daily operation
- ▶ Designed for application in hay and straw trade

Specifications

Measuring range

9 ... 50%

moisture

Measuring range

temperature

-10 ... 100°C / 14 ... 212°F

Resolution of display 0.1% 0.8% Accuracy

Display LCD with 15 mm / .6 in cipher height

Keypad Membrane keyboard

Handle Stable wooden handle with ergonomic design

Enclosure Resistant to splashes and dust

Lance made of stainless steel with 25 cm, 50 cm, 100 cm Measuring lance

or 200 cm length

Hold function, counting function, average value **Functions**

calculation

Display light Automatic Switch-off Automatic Calibration Automatic **Power Supply** 9V block battery

772 x 70 x 48 mm / 30.4 x 2.8 x 1.9 in (edition with 50 cm **Dimensions**

lance)

800 x 78 x 54 mm / 31.5 x 3 x 2 in(edition with 50 cm

Package size

lance)

Weight incl. battery 650 g / 1.4 lbs (edition with 50 cm lance)

More information

Video



More product info



Similar products

