

deeper

CASTABLE WIRELESS FISH FINDER FOR SHORE ANGLERS

SEE EVERY FISH ON YOUR SMARTPHONE



Deeper START at a glance

- A quick, easy-to-use wireless castable fish finder
- Simple display on smartphone / tablet that's easy to understand
- Great scanning power – down to 165ft / 50m
- Huge casting range to tackle any water – up to at least 165ft / 50m
- WiFi connection for unbeatable connection strength
- New design for easy casting and reeling, and great visibility
- 120kHz scanning frequency and 10 scans per second for readings you can trust
- All scans saved and accessible



THE DEEPER START IS PERFECT FOR ... SHORE ANGLERS WHO JUST WANT TO FIND FISH

Powerful scanning, simply displayed

At Deeper we believe that every angler deserves accurate data they can trust, whatever they need their fish finder for. That's why we've designed a castable fish finder that is simple to use, but has all the power to ensure accurate, reliable readings.

Powerful

- A casting range of at least 165ft / 50m rivals top-of-the-range models and means no location is out of reach.
- Scans down 165ft / 50m so you'll never miss a target.
- WiFi connection ensures solid connectivity and transfers data up to 10X faster than Bluetooth.
- 10 scans per second ensures accurate readings.

Simple

- An easy-to-understand display with all the features you need to find and target the fish - Fish icons, fish sizes, fish alarms, fish depth tags.
- Our lightest ever fish finder, the START is easy to cast and features a new design for even smoother reeling.

Simply find more fish

The START is a fast, effective tool for marking fish from the shore. Displayed through the Deeper App, all the readings from the Deeper START are converted into easy-to-understand icons that tell you everything you need to know:

- **Is it really a fish?** Fish icons show any fish detected by your fish finder.
- **How big is the fish?** Small, medium and large fish sizes help you target the trophies.
- **At what depth is the fish?** The depth tag next to each fish icon tells you exactly how deep the fish is suspended. Now you know exactly which depth to set your lure or jig to.
- **Have I missed a fish?** The fish alarm will tell you whenever the START marks a fish.

Finding fish from the shore has never been simpler.

All the power of a Deeper

The Deeper START boasts all the scanning power anglers have come to expect from Deeper.

- Huge casting range of at least 165ft / 50m matches the top-of-the-range models of our competitors.
- Now no spot is out of range – if you can cast there, you can scan there.
- Deep waters are no problem – the START scans down to 165ft / 50m.
- With a minimum scanning depth of 1.6ft / 0.5m, it can tackle the shallows too.

A fish finder you can trust

The Deeper START has just the right specs for accurate, reliable fish finding:

- **WiFi connection** – Gives a much stronger connection, bigger range and up to 10X faster than a Bluetooth connection for more accurate data.
- **10 scans per second for improved accuracy** – Every second the Deeper START sends and receives 10 sonar pulses, so your display is constantly being updated with new data, improving accuracy.
- **40° scanning cone for good accuracy and area coverage** - The START's single beam, 120 kHz sonar scans in a 40° cone giving the right balance between wide area coverage and good accuracy.

Light and easy to cast

The START is our easiest sonar to cast and reel in, and has great visibility too:

- At 65g/2.3oz, the Deeper START is our lightest ever sonar so there's no need to worry about line breaks.
- It's possible to cast the START with virtually any line and rod – no need for specialist gear. All our sonars are tested to cast using 6lbs / 2.7kg and 7.6lbs / 3.4kg test

monofilament line, and 16lbs / 7.2kg and 20lbs / 9kg test braided line.

- The START features a new design, with a rounded base and cone-like top, making it even easier to reel in smoothly.
- Plus it comes with an inbuilt LED to ensure your fish finder remains fully visible.

An incredible fishing record at your finger tips

Every scan you make is recorded and saved, which means you can:

- identify and **return to the best spots**,
- **review every scan** in detail.

And this is just the start:

- The **notes function** on the app lets you keep detailed records of every spot you fish.
- Use the **in-app maps** – free to download and then available offline – to mark and save your hotspots.

Simple to set up and charge

The START has ground-breaking design features that make it incredibly simple to charge and maintain:

- Easier to charge with no removable cap.
- Charge the device using the custom-built magnetic USB cable that comes with the START.
- The START automatically switches on when in water, and off when out of water, helping to conserve battery.
- Comes with a barrel swivel already attached, so it's ready to use straight out of the box.

A sonar to suit every angler

With the introduction of the Deeper START, there is now a high quality Deeper Sonar for all fishing styles and budgets.



deeper



How it works

- Cast out
- Scan and reel in
- See fish and depth on your phone

What's in the box

- Deeper START smart fishfinder
- USB wire
- Swivel
- Quick start guide

Product Tech Specs

Material	ABS
Compatibility	From iOS 9.0 and Android 4.1 to the latest iOS and Android devices
Sonar Type	Single beam
Frequency (Beam cone)	120 kHz, 40°
Depth Range Max/Min	Max 165ft / 50 m, Min 1.6ft / 0.5 m
Sonar Scan rate	10 scans per second
Operating Temperature	0°C to 40°C/32°F to 104°F
Internal Battery	Lithium Polymer, 3.7V Rechargeable, 850mAh
Power Supply input (for charging battery)	5V DC, 650mA max
Power Adapter (not included in the box, recommended)	Input AC 110V/240V. Output Micro USB A, 5V 450mA
Connection type	Wireless Wi-Fi connection 802.11 b/g 2.412GHz 1channel 802.11 b +10 dBm, sensitivity -91dBm 802.11 g +10 dBm, sensitivity -75dBm
Connection Range	Up to at least 165ft / 50m. Range depends on the OS and smartphone model
Battery Life	Up to 6 hours
Charging Time	2.5 hours
Color	Black and Orange

Product Logistics Specs:

Model	ITGAM0431 (Global), ITGAM0459 (Asia)
EAN	4779032950428 Global / 4779032950435 Asia
Product size	60 x 65 x 65 mm / 2.3 x 2.5 x 2.5 in
Product weight	2.3oz / 65 g
Retail packaging size	110 x 110 x 80 mm / 4.33 x 4.33 x 3.15 in
Retail packaging weight	300 g / 10.58 oz
QTY per multipack	N/A
Multipack weight	N/A
Multipack size	N/A
QTY per master-pack	45
Master-pack weight	14,5 kg / 32 lbs
Master-pack size	56 x 34 x 25 cm / 22.05 x 13.39 x 9.84 in
Harmonized customs code	9014800000
Country of origin	Made in Lithuania

For the full range of Deeper products and accessories go to: DEEPERSONAR.COM/EN/PRODUCTS